

## CC-400HF Quick Start Guide




## Proper Startup Essentials



Replace the red cap with the black cap









Attach the spray gun to the quick connect of the high-pressure hose.



Attach the water supply hose to the water inlet on the output of the pump and turn the water on.








Let go of the trigger and put the soap dip tube into your container

and allow it to run water for 20-30 seconds.
(Note: do not attach any of the additional nozzles to the gun during this step).

While holding the trigger, turn on the machine







Attach either the black nozzle or wonder-wand to the spray gun's quick connect to siphon and apply soap.





Attach the yellow nozzle to the spray gun's quick connect to rinse.

(Note: You can use the wonderwand to rinse

use the wonderwand to rinse but you must remove the dip tube from the COILSHINE chemical).





## 

## **HVAC & FACILITY MAINTENANCE SOLUTIONS**

GOODWAY\* TECHNOLOGIES CORPORATION 420 West Avenue, Stamford, CT 06902 USA Tel: 203-359-4708 · Toll-Free Tel: 800-243-7932 Fax: 203-359-9601 · Toll-Free Fax: 800-359-9625 Email: goodway@goodway.com Visit: www.goodway.com