Advanced Artillery For Enhanced Tubes


These brushes are designed to clean the lands and grooves of internally enhanced tubes.



Note: All Goodway brushes and buffing tools are available with standard threaded tool couplings. To order, remove the "Q" from the part number.



BRUSHES FOR INTERNALLY ENHANCED TUBES



SMALL DIAMETER OF BRUSH CLEANS LANDS



The"Patriot®" Dual Diameter Nylon Brush:

The "Patriot" Dual Diameter Nylon Brush is recommended for removing soft deposits (mud, algae, etc.) in straight, ferrous and nonferrous internally enhanced tubes. The large diameter end of this brush cleans into the grooves while its small diameter end cleans the lands of the tube's rifling.

Available in Bags of 25

ENN-062-Q BRU00183 The "Patriot" Dual Diameter Nylon Brush for tubes 1/5 I.D. **ENN-090-Q BRU00448** The "Patriot" Dual Diameter Nylon Brush for tubes 15/16" I.D.



Dual Diameter Spin-Grit Brushes:

Spin-Grit Brushes is recommended for removing soft and light scale deposits in straight, ferrous and nonferrous internally enhanced tubes. The small diameter end of this brush cleans into the grooves while the large diameter end cleans the lands of the tube's rifling.

Available in Bags of 15

ESGB-Q-062 BRU00184 for \(\frac{5}{8} \)" I.D tubes. Also, available in other sizes.

BRUSHES FOR SMOOTH BORE TUBES



Blue Nylon Brushes:

Blue Nylon Brushes are recommended for removing soft deposits (mud, algae, etc.) in straight, ferrous and nonferrous tubes. Brush should be equal to or 1/16" smaller than tube I.D. A

Available in Bags of 15 or 25 – Depending on Size

GTC-211-5/8 BRU00169 for 5/8" I.D tubes. Also, available in other sizes



Brass Brushes:

Brass Brushes are recommended for removing soft and light scale deposits in straight, ferrous and nonferrous tubes. Brush should be equal to or 1/16" smaller than tube I.D.

Available in Bags of 15

GTC-200BQ-5/8 BRU00232 for %" I.D tubes, Also, available in other sizes



FOR MORE INFORMATION CONTACT



Goodway Technologies Corporation 420 West Avenue Stamford, CT 06902-6384 U.S.A. Tel: +1-203-359-4708 • Fax: +1-203-359-9601 E-Mail: goodway@goodway.com WWW.goodway.com BRUSH-TR1110B