

SAVE TIME AND SAVE ON CHEMICAL COSTS



BioSpray® 10 and 20 Portable Systems for Industrial Environments

BioSpray surface sanitizing systems from Goodway Technologies are patented, portable systems for faster, safer and more efficient surface sanitizing. The cordless BioSpray systems use an advanced CO₂ delivery technology and lab-calibrated spray gun to apply BIOSPRAY-D2 surface sanitizer with better coverage than traditional pump sprayers.

FEATURES

- Quiet, non-electric, no power source required
- Continuous operation with no downtime*
- Patented freeze-resistant system*
- Highly calibrated delivery system for more effective coverage
- Portable for easy transport and storage
- Hygienic stainless steel design for easy cleaning

*BIOSPRAY-20 only

	BIOSPRAY-20	BIOSPRAY-10
Input Power	None. Uses internal CO ₂ cylinder	None. Uses internal CO ₂ cylinder
Hose Length	20'	20'
Operating Pressure	24-26 PSI	24-26 PSI
Tank	20 lb CO ₂	10 lb CO ₂
Dimensions (DxWxH)	18" x 28" x 44"	25" x 16" x 40"
Weight	100 lbs	86 lbs

APPLICATIONS

- Tools
- Motors
- Freezers
- Control panels
- Proximity switches
- Dry production areas
- Packaging machines
- Labelers
- Slicers
- Scales
- Belts
- Robotics
- General surfaces
- Food contact surfaces
- And much more

BIOSPRAY-20: Portable, cordless CO₂ sprayer system, with one (1) 20 lb CO₂ tank, for the application of BIOSPRAY D2 sanitizer. **Call for Information and Pricing**

BIOSPRAY-10: Portable, cordless system with one (1) 10 lb tank, for the application of BIOSPRAY-D2 sanitizer. **Call for Information and Pricing**

BIOSPRAY® D2 SURFACE SANITIZER

BioSpray D2 sanitizer and disinfectant is ready-to-use, no-rinse, highly evaporative, non-corrosive and fast acting. Ideal for water sensitive equipment like motors, tools, classrooms, hospitals, control panels, and more. BIOSPRAY-D2 is an EPA registered isopropyl alcohol and powerful quaternary surface sanitizer. The product is a ready-to-use, quick-drying disinfectant. It eliminates 99.9% of tested pathogens in 10 seconds on non-food contact surfaces and 99.999% of tested pathogens in 60 seconds on food contact surfaces.



See more details on page 150



1-800-333-7467

www.goodway.com

420 West Avenue, Stamford, CT 06902-6384 U.S.A. | 203-359-4708 | Fax: 203-359-9601 | goodway@goodway.com

Goodway is not responsible for typographical errors in product descriptions or pricing. Product availability and features may change. Actual products may differ slightly in appearance to images shown. Please contact Goodway with any questions prior to purchase. © Crossford International. All Rights Reserved.